Unilab COILS 7.x

Network Activation Key
Installation Guide

UNILAB S.r.l. – Via N. Bixio 6 – 35131 – Padova (PD) – Italy – Tel.: +39 (0)49 8763311 – Fax: +39 (0)49 8750196
www.unilab.eu – info@unilab.eu


The NETWORK activation of Coils 7.x requires the usage of a "Server" computer that will give the licenses available of coils to the users that wish to use the software.

"Server" Computer system requirements

32 bits (x86) or 64 bits (x64) processor from 1 GHz or faster
1 GB of RAM (32 bit) or 2 GB of RAM (64 bit)
2 GB of free storage space on the hard disk
CD drive and at least one free USB slot

Software and USB dongle installation

1. Let's insert the usb dongle in a free usb slot.
2. Let's wait some seconds, intanto che i driver vengono installati automaticamente.
3. Open "My computer".
4. Create two folders on the "C:" drive, one named "CoilsMxNet" and "MxNet".
5. Insert the CD of Coils 7.x that was sent to in the CD drive of the "Server" pc.
6. Open "Risorse del computer" ed entrare nella cartella "Network" del CD.
7. Open the "MxNet.zip" file and unzip its content in the "C:\MxNet" folder just created.
8. With "Windows Explorer", go in the folder "C:\MxNet".
9. Let's right click on "MxNet.exe" and choose "Run as Administrator":




Configuration of the activation software

1. When we start the software "MxNet.exe" an icon next the clock will appear in the tool bar:




2. When we click on the same, the following will appear:




3. In the lower half, at the height of the fields "Application", "Server-file", etc., write the following parameters:

Application: "Coils Net" (without the quotation marks)
Server-File: "C:\CoilsMxNet\CoilsNet.mx" (without the quotation marks)
Refresh-Time: 1 min.
User-TimeOut: 5 min.

4. Let's click on "New entry" to confirm the inserted data. The following will appear on top:



5. Let's click on "Settings" on the right:



6. Please check "Start Matrix-NET at system startup":




7. Click on "Ok" and reboot the "Server" pc.


Sharing of the "CoilsMxNet" folder

Now let's configure the folder "CoilsMxNet" so that it will be shared on all the pcs on the network.


1. Let's right click on the "CoilsMxNet" folder, and choose "Properties":




2. The following window will appear:




3. Click on the "Sharing":




4. Let's click on "Advanced Sharing" – administrator rigths migth be necessary for this operation. Contact your IT administrator for further details. In the new window, let's choose "Share Folder":




5. Let's click on "Authorizations" and make sure to have the user "Everyone":




6. If not present, please click on "Add". In the new window let's write "Everyone" and click on "Ok":




7. Once assured that it is present, let's add the "Full control":




8. Finally let's click on "Ok", to close the window. Now choose the "Security" from the previous window:




9. Click on "Modify":




10. in the new window, click on "Add":




11. Specify "Everyone" to add the user everyone and click on "Ok":



12. Choose the new user and give to the same the authorization to the "Full control":



13. Let's click on "Ok" to go back on the previous window:




14. Let's click on "Close" to complete the procedure.


Coils Configuration

1. Start Coils by double clicking on its icon.


2. Once it started, the following window will appear:




3. Let's specify the second option:



4. Let's click on "Next". The following message will appear:



5. Let's click on "Yes". Now we need to specify the "CoilsNet.mx" file path, which is in the shared installation folder previously created:



6. After we have chosen the file, let's click on "Open" and wait that the software starts.